


SPINCASTING REEL 512RL



Key No. 3 ~ 5

6-736-7801 Rotor assembly \$ 4.60

Key No. 16 ~ 19

6-711-5301 Main shaft assembly \$10.45

Key No.	Parts No.	Parts Name	Price Per Piece	Key No.	Parts No.	Parts Name	Price Per Piece
1	6-755-2001	Front cover	\$5.35	26	6-501-8501	Handle screw holder	\$.20
2	6-342-3701	Rotor nut	.35	27	6-363-8501	Handle screw A	.35
3	6-736-7901	Rotor	See Assy.	28	6-363-6002	Handle screw cap	.70
4	6-142-5111	Pick up pin spring	.15	29	6-637-4801	Drive gear shaft holder	.20
5	6-783-0201	Pick up pin	1.20	30	6-414-1901	Drive gear	.95
6	6-321-1001	Spool retainer	.40	31	6-481-3101	Oscillating slider	.25
7	6-376-1901	Spool washer A	.15	32	6-375-0502	Drive gear washer A	.15
8	6-376-2101	Spool washer B	.40	33	6-280-9301	Ratchet	.35
9	6-734-3501	Spool	3.00	34	6-370-9920	Drive gear washer B	.15
10	6-376-2101	Drag washer A	.40	35	6-637-4501	Bearing metal	.25
11	6-376-2001	Drag washer B	.20	36	6-707-0701	Body cover	1.85
12	6-151-9101	Drag adjusting plate	.45	37	6-111-7011	Anti-reverse claw	.15
13	6-783-0111	Oscillating plate	2.85	38	6-144-5111	Anti-reverse claw spring	.15
14	6-364-0511	Drag adjusting screw	.80	39	6-350-1931	Anti-reverse claw screw	.15
15	6-382-1801	Shaft metal	1.30	40	6-461-4501	Anti-reverse cam	.35
16	6-394-1301	Main shaft	1.20	41	6-144-5001	Anti-reverse cam spring	.15
17	6-637-2101	Ball bearing	6.30	42	6-541-3132	Anti-reverse lever	.25
18	6-402-6701	Pinion gear	.80	43	6-351-4701	Anti-reverse lever screw	.15
19	6-142-7711	Main shaft spring	.15	44	6-353-0001	Body cover screw (short)	.15
20	6-701-5601	Body	6.00	45	6-353-4911	Body cover screw (long)	.20
21	6-352-2201	Collar stopper screw	.15	46	6-071-0504	Drive gear shaft	1.40
22	6-502-0101	Drag adjusting collar	.60	47	6-747-8201	Handle	2.75
23	6-151-9001	Drag spring washer	.20	48	6-160-8001	Handle washer	.15
24	6-441-6201	Drag adjusting dial	.40	49	6-363-5301	Handle screw B	.55
25	6-781-6508	Push button	.90				